

Replacement of the freewheel body (Road)

WH-7800 / FH-7800

- Remove the freewheel body fixing nut (inside the freewheel body), and then replace the freewheel body.
(The freewheel body fixing nut has a left-hand thread.)
- Special grease is used for the freewheel body.
Do not mix it with other types of grease, as this may cause problems with the operation of the freewheel clutch mechanism.
(Grease part number: Y-3B980000)

Note:
Do not attempt to disassemble the freewheel body, because it may result in a malfunction.

Tightening torque:
10 - 15 N · m
{86 - 130 in. lbs.}

